


Welcome to

witschi




🇨🇭 LEADING SWISS PRODUCTS

Witschi Electronic AG

Bahnhofstrasse 26 – CH-3294 Büren a.A. – Tel. +41 (0)32 352 05 00
Fax +41 (0)32 351 32 92 – welcome@witschi.com – www.witschi.com

witschi

Quartz knowledge for professionals



LEADING SWISS PRODUCTS

Witschi Electronic AG

Bahnhofstrasse 26 – CH-3294 Büren a.A. – Tel. +41 (0)32 352 05 00
Fax +41 (0)32 351 32 92 – welcome@witschi.com – www.witschi.com



05/10
UH



Contents

Components in detail

- Batteries
- Quarz
- IC / regulation systems
- Control of the stepping motor (asservicement)


Systematic trouble shooting

Calculation of the battery service life

Service philosophie – quartz watches

Batteries

Construction (Cutaway view of a silver oxide cell Zn/Ag₂O)



1: Can

2: Cathode (AG20)

3: Support ring

4: Separator

5: Gasket

6: Electrolyte (NaOH or KOH)


7: Anode material (Zn)

8: Anode cap



Batteries

Capacity dependence vs. Temperature(mAh)




Typical temperature effect on miniature silver oxide batteries



Batteries

Typical self discharge rate at different storage temperatures




Nominal Capacity in mAh (100%)
(Silver oxid / Zn Ag₂O system)

~ minus 7-8% after 10 years
at 0°C / 32°


~ minus 15% after 7 years
at 20°C / 68°F

~ minus 30% after 4 years
at 40°C / 104°F



Batteries

Difference between High Drain and Low Drain Batteries



Efficiency (Voltage drop) of typical

Low Drain battery with
NaOH (Sodium)Electrolyte

VS (equivalent size / 357)

High Drain battery with
KOH (Potassium) Electrolyte




Batteries

Calculation of battery life under different user conditions:

Example: Quartz Alarm Chrono / Battery type: 1.55 Volt 55mAh

Function	Current consumption	Usage time per day	Current consumption per day	Total current consumption per day
Stepping motor Time	1.5 μ A	24 h	36 μ Ah	36μAh
Chrono	Not needed	→		
Alarm	Not needed	→		

Battery Capacity: 55 mAh = 55000 μ Ah : **36 μ Ah** = Service life of: 1527 days or **50 months**



Batteries

Calculation of battery life under different user conditions:

Example: Quartz Alarm Chrono / Battery type: 1.55 Volt 55mAh

Function	Current consumption	Usage time per day	Current consumption per day	Total current consumption per day
Stepping motor Time	1.5μA	24 h	36μAh	60μAh
Chrono	8 μA	3 h	24μAh	
Alarm	Not needed	—————→		

Battery Capacity: 55 mAh = 55000 μ Ah : **60 μ Ah** = Service Life of: 916 days **or 30 months**



Batteries



Calculation of battery life under different user conditions:

Example: Quartz Alarm Chrono / Battery type: 1.55 Volt 55mAh

Function	Current consumption	Usage time per day	Current consumption per day	Total current consumption per day
Stepping motor Time	1.5 μ A	24 h	36 μ Ah	66.6μAh
Chrono	8 μ A	3 h	24 μ Ah	
Alarm	1200 μ A	20 seconds = 0.0055 h	6.6 μ Ah	

Battery Capacity: 55 mAh = 55000 μ Ah : **66.6 μ Ah** = Service Life of: 826 days **or 27 months**

Quartz



Quartz

Construction






Fig. 1 and 1.1

Shows a typical quartz tuning fork used for quartz watches on the base of its container.

Its two branches are animated by an antiparallel oscillatory movement (flection) in the plane of the tuning fork.


Fig. 1.2

Represents a section of the branches of the tuning fork, shows how the electrodes are connected, as well as the electric fields which are formed inside the crystal.



Quartz

Technical features



Frequency vs. Temperature

Dependency

Original formula:

$$\frac{\Delta F}{F_0} = 0.038 \frac{\text{ppm}}{^{\circ}\text{C}^2} (T - T_0)^2 \pm 10\%$$

$$1 \text{ ppm} = \frac{86400 \text{ sec/day}}{1'000'000} = 0.0864 \text{ sec/day}$$

Calculation Example:


Delta Temperature to Inverse point = 10°

$$0.038 \text{ ppm} \times 0.0864 \text{ s/d} \times 10^{\circ/2} (100^{\circ}) = -0.32 \text{ s/d}$$



Quartz

Conclusion / Adjustment





At room temperature, the quartz rate on movements with variable trimmer systems should be adjusted always on a level of

+ 0.10 to + 0.20 seconds / day

Never on 0.00 seconds per day or less (minus values)




IC and Stepping motor






IC


Rate adjustment systems



Adjustable oscillator frequency by trimmer (old system)



Oscillator frequency adjusted by fix cap. (e.g. Used for stop watches)




Rate adjusted by Inhibition systems

- EEPROM (re-programmable)
- OTP (one time programmable)


IC

Motor-Management systems (asservissement)




IC Type without asservissement.
Motor output: Fixpulse
Without any control of the requested minimum energy to move the hands.
Mainly used in cheap calibers

IC Type with asservissement.
Motor output: Chopped puls
Two-way control between rotor and IC.
Management of the requested minimum energy to move the hands and to extend the service life of the battery.
Mainly used in sophisticated movements. (ETA /Ronda/ Miyota)




IC

Motor- Management function (asservissement)



4- 12 ms / 20-30ms / 30-35 ms / 1 second
Timing





Time: 4 – 12 milliseconds (ms)




IC - Motor-Management

Function mode of the motor drive stages of watch IC with adaptive pulses (asservissement)

Symbolically drawn motor pulses (+ / -)



Data sheet (Philips). Typical watch IC with adaptive motor pulses (asservissement)



Stage 1 = Lowest stage: 56.25% of 7.8ms = 4.38 ms

Stage 2 = 62.50 % of 7.8 ms = 4.87 ms net pulse width




Stage 6 = 100 % of 7.8 ms

Constant pulse width (example 7.8ms)



IC - Motor-Management

How does it work?





Systematic troubleshooting | Quartz Watches

Tests and settings

Battery test

TESTMODE MODULE: battery test

Caution:

Always check the movement for corrosion and the **insulation** of the battery case!


Test sequence

Situation: watch stopped

Remove and test the battery

Battery not
ok

Battery ok



Systematic troubleshooting | Quartz Watches

Battery test


TESTMODE MODULE: battery test


Caution: Always check the movement for corrosion and the **insulation** of the battery case!

Test of the coil resistance and of the insulation values:

TESTMODE MODULE: resistance

Situation: watch stopped





Systematic troubleshooting | Quartz Watches

Test of the coil resistance and of the insulation values:

TESTMODE MODULE: resistance

Test of the quartz and IC operation:

TESTMODE RATE: stepp.motor

TESMODE MODULE: cons. μA

PARAMETER: supply voltage 1.55V-3.00V

- Winding stem - POS: Reset

Test of the coil resistance
coil and movement insulation,
without external power supply
and **without** battery

Values ok


Values not ok

Test of quartz and IC
- place watch on the mirror
support, connect external power
supply **MODULE SUPPLY** to the
battery connectors

Values ok

Values not ok

Replace the electronic
module



Systematic troubleshooting | Quartz Watches

Test of the quartz and IC operation:

TESTMODE RATE: stepp.motor

TESMODE MODULE: cons. μ A

PARAMETER: supply voltage 1.55V - 3.00V

- Winding stem - POS: Reset

Test of the stepping motor:

- Winding stem - POS: Neutral

TESTMODE RATE: stepp motor

TESTMODE MODULE: cons. μ A

PARAMETER: supply voltage 1.55V - 3.00V

meas.time rate = > 60 s

meas.time cons. 60 s

TEST CONTROL: start test

Test of quartz and IC

- place watch on the mirror support, connect external power supply **MODULE SUPPLY** to the **battery connectors**


Values ok

Values not ok

Test of the stepping motor

- place watch on the mirror support, connect external power supply **MODULE SUPPLY** to the **battery connectors**

Replace the electronic module



Systematic troubleshooting | Quartz Watches

Test of the stepping motor:

- **Winding stem - POS: Neutral**

TESTMODE RATE: stepp motor

TESTMODE MODULE: cons. μ A

PARAMETER: supply voltage 1.55V - 3.00V

meas.time rate \Rightarrow 60 s

meas.time cons. \Rightarrow 4 s

TEST CONTROL: start test

Test of the starting voltage

- Same test as stepping motor;
- battery test tip with RT/T measuring point of the movement

Start with:

PARAMETER: supply voltage 1.55-3.00V

Voltage reduced until the movement stops

Test of the stepping motor


- place watch on the mirror support, connect external power supply **MODULE SUPPLY** to the **battery connectors**

Test of the lower starting voltage

- place watch on the mirror support, connect external power supply **MODULE SUPPLY** to the battery connectors, and the negative test probe with RT/T

Values ok
- **new battery**
- **close watch**

Values not ok



Systematic troubleshooting | Quartz Watches

Test of the starting voltage

- Same test as stepping motor;
- battery test tip with RT/T measuring point of the movement

Start with:

PARAMETER: supply voltage
1.55-3.00V. Voltage reduced until the movement stops

Mechanical test

Test of the lower starting voltage

- place watch on the mirror support, connect external power supply **MODULE SUPPLY** to the battery connectors
- **minus** battery test tips **to the test point RT/T** of the movement

Values ok
- **new battery**
- **close watch**

Values not ok

Important mechanical tests:

- steel particles block the rotor/gear train
- particles between crown and case block the reset mechanism
- hands touch the inside face of the glass
- hands have no axial freedom
- Calendar mechanism

Service philosophy for quartz watches

What is the difference between the quality of service for mechanical- and quartz watches ?




Expensive mechanical
watch for 10'0000 \$



Expensive jewellery quartz
watch for 10'0000 \$

The difference is **zero (0) \$**.
Equivalent to the requested service quality from the customer

Thank you for your attention



LEADING SWISS PRODUCTS

Witschi Electronic AG

Bahnhofstrasse 26 – CH-3294 Büren a.A. – Tel. +41 (0)32 352 05 00
Fax +41 (0)32 351 32 92 – welcome@witschi.com – www.witschi.com



05/10
UH